



QWIK JON® CHOICE MODEL #200

<https://www.zoellerpumps.com/zh-cn/>
<https://zoeller.com.cn/vi/>

**QUICK REFERENCE GUIDE.
SEE INSTRUCTION MANUAL FOR
COMPLETE DETAILS.**




- 1** Connect the rear discharge toilet to the front inlet of the Qwik Jon® Choice. Ensure the connections are in accordance with local, regional, and state codes.




- 2** Connect the drain pipe from another bathroom fixture to the side inlet on the Qwik Jon® Choice. Notice the side inputs have built in check valves and are compatible with many piping sizes. Ensure the connections are in accordance with local, regional, and state codes.




- 3** Connect the discharge pipe to the top of the Qwik Jon® Choice.



- 4** The Qwik Jon® Choice has an inlet on either side allowing side inlet connections from other bathroom fixtures.



- 5** Plug the power cord into a wall socket to provide power to the unit.



© Copyright 2023 Zoeller® Co. All rights reserved.

FIRE/EXPLOSION HAZARD.

Do not pump flammable or explosive fluids such as gasoline, fuel oil, kerosene, etc. Do not use in a flammable and/or explosive atmosphere. Failure to follow these warnings could result in death or serious injury and/or property damage.

**These drawings are for reference only.
Exact components may differ by region.**

ZT0333_EVb 0923
Supersedes NEW



QWIK JON® CHOICE
MODEL #200

<https://www.zoellerpumps.com/zh-cn/>
<https://zoeller.com.cn/vi/>

Hướng dẫn lắp đặt nhanh.
Xem hướng dẫn theo các bước chi tiết sau.




1 Nối ống xả bồn cầu kiểu ngang với đầu phía trước của Qwik Jon® Choice. Đảm bảo các khớp nối gắn khít và chặt chẽ với nhau.




2 Nối ống thoát nước từ một thiết bị cố định trong phòng tắm với một trong đầu nối hai bên (trái hoặc phải) của Qwik Jon® Choice. Lưu ý rằng đầu vào hai bên được tích hợp van kiểm tra và tương thích với nhiều kích cỡ đường ống.




3 Nối ống thoát vào đầu trên nằm bên trên của Qwik Jon® Choice.



4 Qwik Jon® Choice còn một đầu còn lại nằm ở hai bên cho phép nối thêm thiết bị phòng tắm.



5 Cắm dây nguồn vào ổ cắm để cung cấp điện cho thiết bị.



Nguy hiểm cháy/nổ.

Không bơm các chất lỏng dễ cháy hoặc nổ như xăng, dầu nhiên liệu, dầu hỏa, v.v. Không sử dụng trong môi trường dễ cháy và/hoặc dễ nổ. Việc không tuân theo những cảnh báo này có thể dẫn đến tử vong hoặc thương tích nghiêm trọng và/hoặc thiệt hại tài sản.

**Bản vẽ này chỉ mang tính tham khảo.
Độ chính xác có thể khác nhau tùy theo khu vực.**